



TV7 User Manual Apple TV

- TV7 App installation
- Use

Init7

Content

| | |
|----------------|--|
| Page 3 | Requirements |
| Page 4 | Remote Control |
| Page 5 | Install TV7 on Apple TV |
| Page 9 | Channel overview |
| Page 11 | Daily programme |
| Page 12 | Programme description |
| Page 14 | Select audio channel (language) |
| Page 15 | Replay (7 days playback) |
| Page 16 | Switch off |

User Manual Version TV7_AppleTV_201911.


1. Requirements

To use TV7, you need a 4th or 5th generation Apple TV. Connect the box to your TV according to the instructions.



2. How to connect Apple TV?

Connect Apple TV to your TV or any display.



Our recommendation:
If possible, connect Apple TV over a network cable – not over Wi-Fi.

2. Remote Control

Operate Apple TV via the touch surface of the remote control.

Swipe (without clicking) to the right, left or up and down. Once you have made a selection, confirm by clicking OK in the middle of the touch surface.

To return to the Apple menu, press the MENU button.

To turn off Apple TV, press the Home button for 3 seconds and confirm with OK on the touch surface.

The touch sensitivity of the remote control can be set to be slower or faster:

Open the settings on your Apple TV and select the “Remote controls and devices” submenu. You can change the scroll speed under the top tab.




3. Install TV7 on Apple TV

Install TV7 through the App Store.
open the App Store.



3. Install TV7 on Apple TV

Now go to the “Search” tab and press the touch surface.




3. Install TV7 on Apple TV

Type in TV7: Select the individual letters (TV-7) by switching between them with the touch surface and confirming the selection of letters by pressing. For the number 7, first select the number mode under “123” and then select the 7. Now select the Init7 App.



3. Install TV7 on Apple TV

Select "Install". After installation, select "Open" to start the TV7 App.



4. Channel overview

For the channel overview, swipe once from the right edge to the left on the touch surface.



4. Channel overview

To select a channel, swipe up or down.
Confirm the selection by pressing on the touch surface.



Swipe up/down for channel selection



5. Daily programme

Swipe twice from the right edge to the left to display the weekly programme for the current channel (it is not possible currently to view the weekly programme for another channel. You must first change channels).

↑ Swipe up for past programmes
↓ Swipe down for upcoming programmes



6. Programme description

Swipe once from the bottom edge to the top to display a **short** programme description of the programme you are currently watching.



6. Programme description

Swipe twice from the bottom edge to top to display the **full** programme description for the programme you are currently watching.

- A) Swipe left for the previous programme
- B) Swipe right for the next programme



A

B

8. Select audio channel (language)

Swipe down from the top edge to display the audio options for the channel.
Please note that this feature is supplied by the channels and is not always available.
When available, you will also find the teletext subtitle here.



9. Replay (7 days playback)

Did you miss a show? No problem! With TV7 you can replay any programme up to seven days in the past. Swipe twice from the right edge to the left to display the weekly programme for the selected channel. Swipe up or down to show all programmes for the last seven days and replay the desired programme again by pressing on the touch surface when the desired show name is highlighted.



10. Switch off

To switch off Apple TV, press the hibernate button for 3 seconds and confirm with OK on the touch screen.



Home
(Press for 3 seconds)